



Hector 9000

Notes on Assembly

Cadmium, kater, Marv

V0.2a EN as of 2018-10-30

Hector 9000 is a cocktail machine that can pour drinks from 12 different ingredients. Hector 9000 was created at the beginning of 2018 as the successor to Uncle Hector, a pure Gin-Tonic machine. During the development we tried to make as many parts as possible by 3D printing without support. Unlike many other barbots, peristaltic pumps are not used, which makes it possible to pump carbonated drinks. The liquids are conveyed by a slight overpressure in the bottles, at the same time the conveyed quantity is determined by a balance. If enough of a liquid has been dosed, the silicone tubes belonging to the liquid are squeezed off. The drinks do not come into contact with moving parts. When a cocktail is finished, Hector activates its bell.

The core of Hector 9000 is a Raspberry Pi 3B. The Pi takes over the process control and displays the UI on a 7" touch screen. The software is written in Python 3, Kivy is used to provide the graphical user interface.



Contents

1 Disclaimer	4
2 Hardware	4
2.1 Mechanics	4
2.1.1 Scale	4
2.1.2 Pump	5
2.1.3 Valves	6
2.1.4 Arm	6
2.1.5 Bell	10
2.1.6 Hoses	10
2.1.7 Plugs	10
2.1.8 Flushing funnel	13
2.1.9 Housing	13
2.1.10 Display	13
2.2 Electronics	14
2.2.1 General	14
2.2.2 Wiring	14
2.3 BOM	18
3 Software	21
4 Licenses	21
4.1 Hardware	21
4.2 Software	21
5 Revisions	22



List of Figures

1	Scale with glass	4
2	Bottom of the scale	5
3	Airpump	6
4	Valves	7
5	Valves (rear view)	7
7	Endpositions of the arm	8
6	Arm (rear view)	8
8	Mounting of the drip catcher	9
9	Mounting of the bell	10
10	Bell	11
11	Finger with bracket	11
12	Guiding the hoses	12
13	Plugs	12
14	Flushing funnel	13
15	Hector 9000	14
16	Flipped display	15
17	Power supply	16
18	Backpanel removed	16
19	Wiring overview	17
20	GPIO connections	17
21	Connecting the all-round light	17

List of Tables

1	BOM Scale	18
2	BOM Pump	19
3	BOM Valves	19
4	BOM Arm	19
5	BOM Bell	20
6	BOM Plugs	20
7	BOM Display	20
8	BOM Misc.	20



Figure 1: Scale with glass

1 Disclaimer

We accept no responsibility for any injury or damage resulting from the replication and/or operation of Hector 9000.

2 Hardware

2.1 Mechanics

2.1.1 Scale

To measure the poured quantities of the ingredients, a load cell in conjunction with a HX711 is used. Before assembling the printed plastic parts, the overflow pipe must be glued into the scale pan. The balance is bolted on from above through the table top. The length of the spacer and the overflow pipe must be adjusted according to the thickness of the table top, a gap of about 1 mm should be visible between the table top and the scale pan. For the electrical connection we used a CAT5e cable. On the bottom of the housing, it is possible to connect a hose with 10 mm inner diameter for the overflow. The following sequence has proven useful for the assembly of the scale:

1. Screw the cable gland into the housing,
2. Position housing and load cell under the table top,
3. Screw the load cell from the top,
4. Secure spacers and scale pan,
5. Solder cables,
6. Screw on the lid.




Figure 2: Bottom of the scale

2.1.2 Pump

To create the overpressure in the bottles, we use an air pump for fish tanks. Since the complete electronics operate with max. 12 VDC, we opted for a 12 V pump from Schego. The selection of the pump is relatively uncritical since the required pressure and the flow rate are low. It should only be ensured that the pump works oil-free. Because the pump has only one hole for mounting, a bracket has been designed. The following sequence during assembly has proven itself:

1. Screw on 2 nuts at each end of the threaded rods and counter. A nut should be flush with the threaded rod, the key surfaces of the nuts must be in alignment.
2. Insert threaded rods in the holes of the bracket,
3. Screw the bracket into the housing,
4. Insert pump and clamp with the U-profiles (optionally with foam rubber strips under the U-profiles),
5. Counter the nuts (or glue with Loctite).




Figure 3: Airpump

2.1.3 Valves

In order to realize the dosing of the fluids, pinch valves were designed for our cocktail machine which simultaneously open and close both hoses (i.e. air and liquid) for an ingredient. The required plastic parts for the valves can be printed without support. The (optional) cover was cut out of transparent PMMA with a CO₂ laser. Make sure the servos are original *TowerPro MG996R*. There are servos with the same name of no-name vendors. These servos may differ in the outer dimensions, in some cases significantly different from the original servos. The round servo arms supplied with the servos must be adapted to the inner diameter of the cams. Special care is necessary: If the servo arms are eccentric in the cam, the valve will not close properly. Our servo arms were machined on a CNC milling machine with a very sharp wood cutter. The mounting holes for the servo arms are best drilled using the cam as a template. The screws for connecting cam and servo arm are secured with Loctite. Make sure the tongues are made of a material with good sliding properties. Our tongues were printed from *Iglidur I150*. The tongues in the valves of Uncle Hector have been through a few hundred cycles and still work flawlessly. Alternatively, the tongues could be printed from PET, but this has not been tested yet. For the valves to sit flush with the rear wall, cutouts for the servos must be made (Fig. 5). For fastening the valves, captive nuts have been proven.

2.1.4 Arm

In order to make the filling process more comfortable, the arm with the dosing head is retracted in the idle state (Fig. 7). When the dosing process is started, the arm moves forward. All required plastic parts can be printed without support. The gliding insert should be made of a material with good sliding properties. Our gliding insert was printed from *Iglidur I150*. Alternatively, the slide insert could be printed from PET, but this has not been tested yet. The boom consists of an aluminum profile with 15.5 mm edge length. Such profiles can be found in almost every German DIY store. The pinion is pressed onto the shaft of the motor and needs no further securing. To attach the rack to the boom, M3 blind rivet nuts were inserted into the profile. The dosing head is secured with a self-tapping screw in the profile. The trigger



Figure 4: Valves





Figure 5: Valves (rear view)



(a) Arm retracted

(b) Arm moved forward

Figure 7: Endpositions of the arm

is glued to the boom. The trigger has a hole through which a cable was routed to power an optional all-round light on the arm.

When mounting the arm, make sure that the bottom bolt is passed through the hole from the rear and screwed down with a regular nut. The upper bolts are inserted from the front through the rear wall. The drip catcher can now be mounted on the lower screw with a knurled nut (Fig. 8).




Figure 6: Arm (rear view)




Figure 8: Mounting of the drip catcher



Figure 9: Mounting of the bell

2.1.5 Bell

When building the mechanism for the bell, make sure that the center of the bell is 100 mm away from the rotational axis of the arm. A bracket is provided for attaching the bell (Fig. 9). To drill the necessary holes in the bell, the bracket is used as a drilling jig. The mounting of the finger on the back wall is actually self-explanatory. To attach the motor bracket (Bell_servo-bracket.stl) to the rear panel, it is advisable to use captive nuts or threaded inserts, so the finger can be easily adjusted later (Fig. 11).

2.1.6 Hoses

To transport liquids and air, silicone hoses with an outer diameter of 6 mm and 4 mm inside diameter are used. In any case, care must be taken that the hoses are intended for use with food. To guide the hoses through the housing, the valves and the dosing head, it has been proven to cut off one end at an acute angle. For each ingredient, two hoses are passed through a valve. One hose directs the liquids from the bottle to the dosing head, the other hose connects the air pump and the bottle. When guiding the hoses through the housing, care must be taken that the hoses do not tangle with the arm. We just used cable ties (Fig. 12).

2.1.7 Plugs

The plugs consist of a 3D printed core and a conical seal. The seal makes it possible to connect different beverage bottles with one kind of plug. The seals can be purchased from catering supplies. When printing the cores, food grade filament should be used. On one side of the plug are the hoses leading to the valves (do not confuse air and beverage hoses!) connected. On the other side of the plug is a piece of silicone tubing connected which reaches to the bottom of the bottle.



Figure 10: Bell



Figure 11: Finger with bracket




Figure 12: Guiding the hoses




Figure 13: Plugs




Figure 14: Flushing funnel

2.1.8 Flushing funnel

As it takes a lot of water and time to rinse the hoses, it is not much fun to stand next to Hector and empty full glasses during the wash program. We have therefore constructed a flushing funnel that transports the wastewater directly into a bucket or spout. The flushing funnel can be printed without support. The hose nozzle is designed for a silicone hose with an internal diameter of 10 mm.

2.1.9 Housing

The housing consists of 25 mm aluminum profiles that have been covered with aluminum sheets and PMMA sheets. The metal sheet on which the scale was attached, as well as the sheet metal which carries the valves, were additionally glued to an MDF board. Before bonding, captive nuts were placed into the MDF panels to later screw on the DIN rails and pump. The PMMA plates and most of the other plates were fixed with 4 mm blind rivets. The rear wall is fixed by M4 screws. Blind rivet nuts were used in the profiles as a counterpart to the screws. It is strongly recommended to use special sheet metal drills for machining the sheets and profiles, otherwise problems may occur when inserting the rivets. The case is not included in the bill of materials, here everyone should let their creativity run free¹.

2.1.10 Display

For the selection of drinks we have opted for a 7" display with touch function via USB. The USB version is necessary because the GPIOs are used for other functions. The display is attached to a extruded profile of the housing. For transport the display can be turned into the housing (Fig. 16). In the printed housing for the display are 3 holes for mounting it to the frame. Only two holes are needed for the attachment: the middle hole and an outer one. The display is screwed to the frame by means of blind rivet nuts and knurled screws. To turn the display, remove the outer screw and loosen the center screw.

¹Besides, we do not have complete CAD data for the case ;)




Figure 15: Hector 9000


2.2 Electronics

2.2.1 General

We decided to realize the power supply of Hector 9000 with a PC power supply. It is recommended to place the voltage outputs of the power supply unit on terminal blocks and to carry out the cable routing in wiring channels. We have fused the supply voltage of the LED strips, also on terminal blocks. It is also useful to make the connections between the modules by crimped connectors.

2.2.2 Wiring

The interconnection of the individual components (Fig. 19) is relatively simple. We recommend placing the HX711 board as close as possible to the Raspberry Pi in order to keep the I2C lines short. For the illumination two WS2812B LED strips were connected in parallel to the GPIO of the RPi. There are 15 LEDs in the lower compartment (bottles) per line and 30 LEDs in the upper compartment of the housing. The pinout of the Raspberry Pi can be seen in Fig. 20. The optional all-round light must be switched via a transistor (Fig. 21).



(a) Display half flipped



(b) Display flipped

Figure 16: Flipped display




Figure 17: Power supply




Figure 18: Backpanel removed




Figure 19: Wiring overview




Figure 20: GPIO connections




Figure 21: Connecting the all-round light



2.3 BOM

The BOM only lists components that are necessary to manufacture the individual assemblies. **Cables, plugs, DIN rails, wiring channels, material for mounting the modules in the housing, etc. must be put together individually depending on your housing.** In the column *Source* is listed where we got the parts; these sources are not an advertisement or recommendation for certain sellers or platforms, but are merely intended to indicate where the material could be sourced.

Table 1: BOM Scale

Qty.	Title	Description	Source
1	Overflow grid	Scale_overflow_grid.stl	3D printed
1	Overflow pipe	Scale_overflow_pipe.stl	3D printed
1	Scale pan	Scale_pan.stl	3D printed
1	Spacer	Scale_spacer.stl	3D printed
1	Case	Scale_cover.stl	3D printed
1	Lid	Scale_lid.stl	3D printed
1	Cable gland M10		eBay
4	Screw for thermoplasts 3x10		Wegertseder
1	Load cell 1 kg with HX711 board		Amazon



Table 2: BOM Pump

Qty.	Title	Description	Source
1	Mounting base	Schego_830_mount.stl	3D printed
1	Schego 830 membrane pump		Amazon
2	Foam rubber strips 13 mm x 70 mm		DIY Store
2	Aluminium U-profile 13 mm x 8 mm x 105 mm		DIY Store
4	Threaded rod M3x65		DIY Store
12	DIN 934 Nut M3		Wegertseder

Table 3: BOM Valves

Qty.	Title	Description	Source
12	Valve body	Valve_body.stl	3D printed
12	Cam	Valve_cam.stl	3D printed
24	Tongue	Valve_tongue.stl	3D printed
12	Cover PMMA	Valve_cover.stl	CNC/Laser
12	TowerPro MG996R servo	only genuine	Hobbyking
24	DIN 965 Bolt M3x8		Wegertseder
48	ISO 7380 Bolt M3x10		Wegertseder
24	DIN 933 Bolt M3x35		Wegertseder
72	DIN 934 Nut M3		Wegertseder
24	DIN 466 Knurled nut M3		Wegertseder

Table 4: BOM Arm

Qty.	Title	Description	Source
1	Mounting bracket	Arm_mount.stl	3D printed
1	Slide insert	Arm_sliding_element.stl	3D printed
1	Rack	Arm_rack.stl	3D printed
1	Pinion	Arm_pinion.stl	3D printed
1	Trigger	Arm_trigger.stl	3D printed
1	Dosing head	Arm_pourer.stl	3D printed
1	Drip catcher	Arm_drip_pan.stl	3D printed
1	Optical endstop		Amazon
1	Pololu A4988		Amazon
1	NEMA 17 Stepper		Amazon
1	Aluminium square tube 15.5x15.5	Lenght depends on your housing	DIY Store
1	DIN 7981 Self tapping screw 2.9x6.5		Wegertseder
4	ISO 7380 Bolt M3x6		Wegertseder
4	ISO 7380 Bolt M3x10		Wegertseder
6	DIN 125 Washer 3.2		Wegertseder
2	DIN 934 Nut M3		Wegertseder
3	DIN 934 Nut M4		Wegertseder
1	DIN 466 Knurled nut M4		Wegertseder
6	DIN 125 Washer 3.2		Wegertseder
2	Blind rivet nut M3x10 flat		Wegertseder



Table 5: BOM Bell

Qty.	Title	Description	Source
1	Bracket for the bell	Bell_base.stl	3D printed
1	Bracket for the motor	Bell_servo-bracket.stl	3D printed
1	Finger	Bell_finger.stl	3D printed
1	TowerPro MG996R servo	only genuine	HobbyKing
1	Bell		Amazon
7	ISO 7380 Bolt M3x10		Wegertseder
7	ISO 7380 Bolt M3x12		Wegertseder
11	DIN 934 Nut M3		Wegertseder

Table 6: BOM Plugs

Qty.	Title	Description	Source
12	Core for the plugs	Rubberplug_core.stl	3D printed
12	Long-Life Corky 0.7l-1.0l		METRO

Table 7: BOM Display

Qty.	Title	Description	Source
1	Cover	Display_lid.stl	3D printed
1	Base	Display_base.stl	3D printed
1	Clamp	Display_clamp.stl	3D printed
1	7" Touch display	Touch function via USB!	Amazon
4	Distance bolt M3 x 10	male-female	Amazon
2	Screw for thermoplasts 3x10		Wegertseder
4	ISO 7380 Bolt M3x16		Wegertseder
4	DIN 934 Nut M3		Wegertseder

Table 8: BOM Misc.

Qty.	Title	Description	Source
1	Adafruit PCA9685 Servo driver		Amazon
1	Raspberry Pi 3B		Amazon
1	PC-PSU		Reichelt
ca. 1.5 m	WS2812B LED Strips	12 VDC version!	Amazon
ca. 30 m	Silicone hose 6 mm x 4 mm	food-safe; do not buy the cheapest one!	Amazon
1	Flush funnel version A or B	Flush-funnel-XY.stl	3D printed



3 Software

Later versions of this document will contain a description of the software. At the moment you will find information about the software only on <https://github.com/H3c702/Hector9000>

4 Licenses

4.1 Hardware

MIT License

Copyright (c) 2018 H3c70r

Permission is hereby granted, free of charge, to any person obtaining a copy of the 3D models and associated documentation files (the "Models"), to deal in the Models without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Models, and to permit persons to whom the Models is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Models.

THE MODELS ARE PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE CONSTRUCTORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE MODELS.

4.2 Software

MIT License

Copyright (c) 2018 H3c70r

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.



5 Revisions

Version	Date	Issue	Editor
0.1	18.06.2018	Initial version	Cadmium
0.2	23.10.2018	Supplementing content	Cadmium
0.2a	26.10.2018	cosmetics & corrections	kater